

Installation Instructions Skiguard Touring Models:



Included inside Skiguard Touring Models:

- Pair of quick-release tie-downs and mounting hardware
- Pair of cargo organizers (ski-rack)
- Set of keys (*tied to the strap in the rear*)

You will need:

- 1 strong friend
- 13mm or ½" deep socket or wrench
- Knife or something with a sharp point
- Tape measure (*not required, but recommended*)
- In some cases, Allen and/or Torx wrenches may be required for disassembly/reassembly of crossbars.

Video Instructions:

Scan QR code below or visit www.skiguard.com/faq



NB: There are many different types of roof racks/crossbars using various methods of mounting techniques. Make sure that you know and follow the manufacturer's instructions and guidelines before installing your Skiguard.

Step 1: Preparing the roof rack/crossbars and Skiguard

On your cross bars, remove the feet from the load bars on one side on both bars. Pass the load bars through the tunnels in the lower half of your Skiguard roof box. Make sure the U-bolts are loosened on the inside of the Skiguard so the load bars can pass through without difficulty.

Step 2: Reassemble the crossbars

Reattach the feet to the load bars, but do not fully tighten as adjustments will be needed later.

Step 3: Lift the Skiguard with crossbars onto the roof of the car

Lift the Skiguard onto the roof of the car. Ensure that it is moved sufficiently forward so that it does not interfere with the rear hatch in open position. It is recommend leaving at least 1cm or ½” of clearance between the Skiguard and the rear hatch.

Step 4: Adjust crossbars and Skiguard position

Adjust the position of the roof box so that it is centered on the middle of the roof and the roof rack. A good way to this without using a tape measure is to gauge it using the antenna, if center mounted, in the rear, and the rear-view mirror in the windshield in the front. Also make sure that the ends of the load bars stick out the same distance on both sides, if applicable.

Step 5: Tighten all screws, nuts and bolts on crossbars and Skiguard.

Tighten all nuts, bolts, and fasteners on the cross bars and inside the Skiguard. Now the cross bars should be securely attached to the car, and the Skiguard tightly and securely fastened to the load bars.

Step 6: Double check fitment and recheck screws, nuts and bolts

Make sure to go back and recheck that all nuts, bolts, straps etc. on cross bars and inside Skiguard are properly tightened on a regular basis.

NB:

You are solely responsible for the safety of you and others by safely installing the cross bars and Skiguard Ski & Cargo Box. Skiguard USA, Inc. is not responsible or liable for any misfortune caused by the failure to properly secure the roof box to the vehicle, as set forth in the Warranty and Disclaimer information.

Skiguard USA, Inc

E-mail: info@skiguard.com

Phone: (720) 223-5459

Mail: 1630, 30th St. #272, Boulder, CO 80301, USA